


Quick Guide

August 2012


Upgrading from AxTrax to AxTraxNG

To upgrade from AxTrax to AxTraxNG:

1. If your version of AxTrax is version 4.25 or higher, skip to Step 7.
2. Back up the database:
 - a. Click **Tools>Database**.
 - b. In the *Select database options* dropdown, select **Backup Now**.




- c. Keep the default folder location.
 - d. Click **OK**.
The database file is saved with the following naming convention:
XXX_Veritrax5_veritrax_vxx.bak
3. Copy the file to the root directory (C:\)
4. Uninstall the AxTrax application.
5. Install AxTrax v4.25 using actual Authentication – user name and password (database password for user sa: **9590693**).
6. Import the database file from Step 1 to AxTrax v4.25:
 - a. Click **Tools>Database**.
 - b. In the *Select database options* dropdown, select **Import earlier database version from Veritrax AS-225/AxTrax AS-525**.



- c. Browse to the root folder (C:\) and select the database file.
 - d. Click **OK**.

7. Back up the database:

- a. Click **Tools>Database**.
- b. In the *Select database options* dropdown, select **Backup Now**.



- c. Keep the default folder location.
 - d. Click **OK**.
- The database file is saved with the following naming convention:
XXX_Veritrax5_veritrax_v23.bak


8. Copy the file to the root directory (C:\)

9. Uninstall AxTrax v4.25.

10. Install the AxTraxNG software.

11. Import the database file from Step 7 to AxTraxNG:

- a. Click **Tools>Database**.
- b. In the *Select database options* dropdown, select **Import earlier database version from Veritrax AS-225/AxTrax AS-525**.



- c. Browse to the root folder (C:\) and select the database file.
- d. Click **OK**.

The application closes while the database is imported.

